

## CONEX Push-in fittings case



Description	
Reference	Includes
<b>MAL RP150</b>	Case with 150 push-in fittings: 50 male straight adaptors: (for tube OD) 10x RPD MR0600 (Ø 6mm) / 10x RPD MR0601 (Ø 6mm) 10x RPD MR0800 (Ø 8mm) / 10x RPD MR0801 (Ø 8mm) 10x RPD MR0802 (Ø 8mm) 40 tapered male elbow 90° (for tube OD) 10 x RPC MR0600 (Ø 6mm) / 10x RPC MR0601 (Ø 6mm) 10x RPC MR0800 (Ø 8mm) / 10x RPC MR0801 (Ø 8mm) 10 parallel male elbow: (for tube OD) 10x RPC MG0601 (Ø 6mm) 30 straight union: (for tube OD) 10x RPU ET0606 (Ø 6mm) / 10x RPU ET0808 (Ø 8mm) 10x RPU ET1010 (Ø 10mm) 20 union tee: (for tube OD) 10x RPT ET0606 (Ø 6mm) / 10x RPT ET0808 (Ø 8mm) 1 tube cutter: R22 CT

